

# SHOWOOD LEG ASSEMBLY INSTRUCTION SHEET

ALLOW 10 MINUTES FOR ASSEMBLY

**1**

1. Make sure you have the following parts:

(4) Legs

2.75" (6) Screws

A PHILLIPS HEAD SCREWDRIVER IS NEEDED FOR ASSEMBLY

**2**

1. Working on a clean surface, turn the sofa on its back with the sofa base facing your work area.  
2. Position leg as shown, approximately 1/4" from outside edges of bottom surface.

Approx. 1/4" from each edge.

Leg

Bottom surface

**3**

1. Attach leg using (2) - 3" screws per leg in holes provided.  
2. Repeat the above procedures for the remaining legs.  
3. Turn the sofa upright and place in the desired location.

Sofa

Leg

2.75" Screw

DWG #: 02221  
COPYRIGHT ASSEMBLY COMPANIES 7-28-97

1 OF 2

#02221

# ASAMBLEA de la PATA HOJA de la INSTRUCCION

DEJE 10 MINUTOS PARA ASAMBLEA

**1**

1. lo ASEGURA TIENE LAS PARTES SIGUIENTES:

(4) PATAS

2.75" (6) TORNILLOS

Un DESTORNILLADOR Es REQUIRIRIO PARA ASAMBLEA

**2**

1. FUNCIONAMIENTO En Una SUPERFICIE LIMPIA, VUELVE EL SOFA En SU INVERSO CON EL PARAMENTO del INVERSO del SOFA SU AREA del TRABAJO.  
2. POSICION LA PATA Como MUESTRA, APROXIMADAMENTE 1/ 4" DEL EXTERIOR BORDES De LA SUPERFICIE del FONDO.

APROXIMADAMENTE 1/ 4" DE CADA BORDE

PATA

SUPERFICIE del FONDO

**3**

1. ATA LA PATA USA (2)- 3" TORNILLOS POR PATA En LOS AGUJEROS PROVEYERON.  
2. REPITA EL PROCEDIMIENTO PRECEDENTE PARA LAS PATAS del QUEDA.  
3. VUELVA EL SOFA DERECHO Y lo PONE En EL DESEO LOCALIDAD.

SOFA

PATA

2.75" TORNILLO

DWG #: 02221  
COPYRIGHT ASSEMBLY COMPANIES 7-28-97

2 OF 2